


Dog Training Elite Chattanooga

Training Document

Using the E-Collar Technologies Remote Collar



Dog Training Elite Chattanooga

Training Document

Using the E-Collar Technologies Remote Collar

Charging

Place the barrel plug into the remote and the collar. Both units can be charged every night to ensure you have a good battery when you need it.

Remote: Turn on or off

Press and hold the big button (L) on the back of the remote for 3 seconds. If turning on, press and hold until the display lights up. If turning off, press and hold until the display turns off. (Note: If you are getting ready to charge, you do not need to turn off the remote.)

Collar: Turn on or off

Find the small red dot on the right side of the remote under the tone/vibrate button (T). Now find the red dot on the collar. If turning on, swipe the dots across each other until you see the green LED. The green LED will blink periodically when it is on. (Tip: use the tone/vibrate button (T) to test if it is on and communicating with the remote). If turning off, swipe the dots across each other until you see the red LED.

Stimulation Level Dial

You can adjust the level of stimulation from 0 to 100. In most cases, you are going to be using very low stimulation – just enough to get the dog's attention. You can lock the stimulation level in place to avoid accidentally changing the level and surprising your dog! To do this, simply press and hold the Stimulation Level Dial until the number in the display blinks.

Momentary Stimulation (*Black S button)

The momentary button will only fire once, no matter how long you hold the button.

Continuous Stimulation (*Red S button)

The continuous button will continue the fire until you release the button. It will eventually turn off after 10 seconds.

Tone or Tapping (aka Vibrate)

To switch between Tone and Vibrate, rotate the Stimulation level dial to Zero (0). Press the Light (L) button and then press the Tone/Tap (T) button. Release both buttons and test by listening for a tone or feeling the vibration on the collar.

Remember: This is NOT a punishment tool. It's not very good at punishment but it is very good as a conditioning tool. EVERY time you intentionally say a command, tap the Black button twice. Keep the stimulation low enough where your dog can sense it but not too high that you see physical responses. Exceptions only apply when the dog is not being compliant when you give a command the first time.